



DLC Series

USER MANUAL

DLC600

Dear Valued Consumer:

Congratulations on your purchase of the **DLC600 Series** display. This User Manual was created for you to get the most out of your new device and assist with the initial setup. Please visit www.minarikdrives.com to learn more about our other drives.

Thank you for choosing **Minarik Drives**!

© 2014 Minarik Drives. All rights reserved.

No part of this document may be reproduced or transmitted in any form without written permission from Minarik Drives. The information and technical data in this document are subject to change without notice. Minarik Drives makes no warranty of any kind with respect to this material, including, but not limited to, the implied warranties of its merchantability and fitness for a given purpose. Minarik Drives assumes no responsibility for any errors that may appear in this document and makes no commitment to update or to keep current the information in this document.

Safety First!

SAFETY WARNINGS



Text in gray boxes denote important safety tips or warnings. Please read these instructions carefully before performing any of the procedures contained in this manual.

- DO NOT INSTALL, REMOVE, OR REWIRE THIS EQUIPMENT WITH POWER APPLIED. Have a qualified electrical technician install, adjust and service this equipment. Follow the National Electrical Code and all other applicable electrical and safety codes, including the provisions of the Occupational Safety and Health Act (OSHA), when installing equipment.
- Reduce the chance of an electrical fire, shock, or explosion by using proper grounding techniques, over-current protection, thermal protection, and enclosure. Follow sound maintenance procedures.



It is possible for a drive to run at full speed as a result of a component failure. Minarik Drives strongly recommends the installation of a master switch in the main power input to stop the drive in an emergency.

Circuit potentials are at 115 VAC or 230 VAC above earth ground. Avoid direct contact with the printed circuit board or with circuit elements to prevent the risk of serious injury or fatality. Use a non-metallic screwdriver for adjusting the calibration trim pots. Use approved personal protective equipment and insulated tools if working on this drive with power applied.

Table of Contents

Section 1. Introduction	1
Section 2. Specifications	2
Section 3. Dimensions.....	3
Section 4. Installation.....	4
Mounting	4
Panel Mounting	5
Wiring	7
Shielding Guidelines.....	8
Connections.....	9
Line Voltage Terminals (G, L1, L2)	9
Output Terminals (S1, S2)	9
Feedback Terminals (+, IN, C).....	10
Inhibit Terminal (INH).....	10
Frequency Terminal (Fin).....	10
Section 5. Operation.....	12
Feedback Device Selection	12
Select Switches	13
Line Voltage Switch (SW501)	13
Encoder Power Supply Voltage (SW502, DIP Switch 1).....	14
Feedback Device Selection (SW502, DIP Switches 2 & 3)	15
Reference Signal Selection (SW502, DIP Switches 4 & 5)	16
Section 6. Calibration	17
MIN and MAX	18
Section 7. Programming.....	19
Calculating Parameters.....	19
Speed Scaling Factor	19
Load Response Number.....	20
Display Scaling Factor.....	20
Gate Time.....	21
Decimal Point Location Number.....	21
Entering the Programming Mode	22
Viewing the Programming Screens	22

Entering Calculated Program Parameters.....	23
Save the Program Settings and Exit the Programming Mode.....	23
Set the Speed	24
Programming Examples	25
Section 8. Leader-Follower Applications	31
Leader-Follower Example Using A Leader Encoder	33
Leader-Follower Example Using Two DLC600's	35
Section 9. Troubleshooting.....	39
Unconditional Warranty.....	41

List of Figures

Figure 1	DLC600 Dimensions.....	3
Figure 2	Panel Cutout.....	5
Figure 3	Inserting the DLC600.....	5
Figure 4	Inserting the Brackets	6
Figure 5	Secure the DLC600	6
Figure 6	DLC600 Connections.....	11
Figure 7	SW501 - Line Voltage Switch	13
Figure 8	SW502, DIP Switch 1 - Encoder Power Supply Voltage	14
Figure 9	SW502, DIP Switches 2 and 3 - Feedback Device Selection ..	15
Figure 10	SW502, DIP Switches 4 and 5 - Reference Signal Selection ..	16
Figure 11	Leader-Follower Connections with a Leader Encoder	34
Figure 12	Leader-Follower Connections with Two DLC600s.....	38

Section 1. Introduction

The DLC600 Series control is a dual-voltage digital control used with a drive, motor, and feedback device to regulate and display motor speed. The user may enter and display the motor speed in RPM or other units, such as feet per minute or inches per second. The DLC600 offers the advantage of repeatable speed settings and speed stability.

Basic operation principles

The DLC600 generates a frequency and compares this to the frequency coming from the feedback transducer attached to the motor shaft. The DLC600 then generates an analog voltage to the speed control to correct for any difference between the the DLC600 reference frequency and the motor feedback frequency.

The DLC600 also counts the motor transducer pulses for a fixed period of time (called gate time) and displays this value on the front panel, usually in the form of motor revolutions per minute.

The DLC600-generated frequency is derived from an internal 50 Hz reference. The generated frequency is equal to the 50 Hz internal reference multiplied by the set speed. The product of the internal reference and set speed is then divided by the speed scale factor (SSF), which is entered by the user via the front pushbuttons. Refer to page 19 for more information on setting the speed scale factor.


Section 2. Specifications

AC Line Voltage	115/230 VAC $\pm$ 10%, 50/60 Hz, 1 ϕ
AC Power	5.5 watts nominally
Acceptable Feedback Sources	5 VDC or 12 VDC NPN-type encoder 5 VDC or 12 VDC NPN-type proximity switch Hall effect sensor Magnetic pickup
Feedback Frequency Range	
External Reference Frequency*	10 - 3000 Hz
External Input Frequency Range**	0 - 500 kHz
Analog Output Voltage Range	0 - 10 VDC
Standard Gate Time	1 second
Power Supply Voltage for Feedback Devices	5 VDC or 12 VDC (10 mA max)
Speed Regulation	0.05% of set speed
Feedback Frequency Range	0 - 3000 Hz
Ambient Operating Temperature Range	50 - 104°F / 10 - 40°C
Weight	approximately 1 lb

* +5 VDC CMOS logic level signal or open-collector NPN transistor; applied to IN and C terminals

** Signal applied to Fin and C terminals. The product of the DLC leader frequency and speed setting may not exceed 500 kHz.

Section 3. Dimensions



ALL DIMENSIONS IN INCHES [MILLIMETERS]

Figure 1. DLC600 Dimensions

Section 4. Installation



Do not install, rewire, or remove this control with input power applied. Failure to heed this warning may result in fire, explosion, or serious injury. Make sure you read and understand the Safety Precautions on page i before attempting to install this product.

Variable speed drives manufactured by other companies may require hookup procedures that differ from those given in this manual. Contact your local Minarik Drives distributor for assistance.

Mounting

- Protect the control from dirt, moisture, and accidental contact.
- Provide sufficient room for access to the terminal block and calibration trim pots.
- Mount the control away from heat sources. Operate the drive within the specified ambient operating temperature range.
- Prevent loose connections by avoiding excessive vibration of the drive.

Panel Mounting

Step 1. Cut a rectangular hole in the panel 1.78 inches (45 mm) and 3.38 inches (86 mm) wide.




Figure 2. Panel Cutout

Step 2. Slide the DLC600 into the panel opening.




Figure 3. Inserting the DLC600

Step 3. Insert the two mounting brackets into each side of the DLC600 case.




Figure 4. Inserting the Brackets

Step 4. Secure the DLC600 to the panel using the bracket screws.




Figure 5. Secure the DLC600

Wiring



Do not install, rewire, or remove this control with input power applied. Failure to heed this warning may result in fire, explosion, or serious injury.

Circuit potentials are at 115 or 230 VAC above ground. To prevent the risk of injury or fatality, avoid direct contact with the printed circuit board or with circuit elements.

Do not disconnect any of the motor leads from the drive unless power is removed or the drive is disabled. Opening any one motor lead while the drive is running may destroy the drive.

This product does not have internal solid state motor overload protection. It does not contain speed-sensitive overload protection, thermal memory retention or provisions to receive and act upon signal from remote devices for over temperature protection. If motor over protection is needed in the end-use product, it needs to be provided by additional equipment in accordance with NEC standards.

- Use 18 - 24 AWG wire for logic wiring. Use 14 - 16 AWG wire for AC line and motor wiring.

Shielding Guidelines



Under no circumstances should power and logic level leads be bundled together. Induced voltage can cause unpredictable behavior in any electronic device, including motor controls.

As a general rule, Minarik Drives recommends shielding of all conductors. If it is not practical to shield power conductors, it is recommended to shield all logic-level leads. If shielding of all logic-level leads is not practical, the user should twist all logic leads with themselves to minimize induced noise.

It may be necessary to earth ground the shielded cable. If noise is produced by devices other than the drive, ground the shield at the drive end. If noise is generated by a device on the drive, ground the shield at the end away from the drive. Do not ground both ends of the shield.

If the drive continues to pick up noise after grounding the shield, it may be necessary to add AC line filtering devices, or to mount the drive in a less noisy environment.

Logic wires from other input devices, such as motion controllers and PLL velocity controllers, must be separated from power lines in the same manner as the logic I/O on this drive.

Connections



Connections to regenerative drives and Minarik Drives XP-AC series drives differ from connections to non-regenerative drives. Improper connection to regenerative or XP-AC series drives may result in damage to the DLC600 or drive.

Variable speed drives manufactured by other companies may require hookup procedures that differ from those given in this manual. Contact your local Minarik Drives distributor for assistance.

Line Voltage Terminals (G, L1, L2)

Connect the line voltage to these terminals. The DLC600 is ON when power is applied to these terminals. Always provide a positive disconnect to shut down the DLC600 in case of an emergency.

Do NOT apply power to the DLC600 until selector switch SW501 has been properly set. See page 13 for details.

Output Terminals (S1, S2)

If using a non-regenerative drive, connect the DLC600 S1 to drive S1 and the DLC600 S2 to drive S2. Refer to Figure 6 on page 11.

If using a regenerative drive, connect the DLC600 S1 to drive S0 and the DLC600 S2 to drive S2. Refer to Figure 6 on page 11.

If using a XP-AC series drive, connect the DLC600 S1 to drive S2 and the DLC600 S2 to drive S1. Refer to Figure 6 on page 11.

Feedback Terminals (+, IN, C)

If using a magnetic pickup, connect the pickup signal lead to terminal IN and the signal common to terminal C.

If an optical encoder is used, connect its positive input voltage lead to +, the signal lead to IN, and the signal common to terminal C. The voltage on the + terminals is determined by DIP switch 1.

Only one feedback source may be used at a time. Refer to Figure 6 on page 11.

Inhibit Terminal (INH)

Short terminal INH to common (C) to inhibit the DLC600. The DLC600 output will drop to the MIN trim pot setting. Remove the short to resume operation. Refer to Figure 6 on page 11.

Frequency Terminal (Fin)

The DLC600 can be used as a signal source to control another DLC600 via SO502 terminals FO+ and FO-. SO502 is a two-terminal, cage-clamp terminal block on the printed circuit board. The frequency output available from these terminals is equal to 50% of the commanded speed. Refer to page 31 for instructions on a leader-follower configuration. The leader DLC may only control one follower DLC. If you are not using the leader-follower configuration, make no connections to Fin, FO+, and FO-.




Figure 6. DLC600 Connections

Section 5. Operation

Feedback Device Selection

Acceptable feedback frequency at any set speed in an application must lie within the 0 - 3000 Hz range. Feedback frequency is directly proportional to the number of feedback pulses per revolution (PPR) and to the speed of the shaft (RPM) that the feedback transducer monitors.

The feedback range relates to the motor speed as follows:

$$\text{PPR}_{\text{minimum}} = \frac{600}{\text{RPM}_{\text{minimum}}} \quad \text{PPR}_{\text{maximum}} = \frac{120,000}{\text{RPM}_{\text{maximum}}}$$

EXAMPLE 1: Consider an application in which the feedback source is monitoring a driven shaft, and not the motor armature shaft. This shaft is running at speeds as low as 1 RPM.

$$\text{PPR}_{\text{minimum}} = \frac{600}{\text{RPM}_{\text{minimum}}} = \frac{600}{1} = 600$$

The selected feedback device must produce at least 600 PPR.

EXAMPLE 2. Consider an application the requires monitoring and controlling a driven shaft at speeds as high as 4000 RPM.

$$\text{PPR}_{\text{maximum}} = \frac{120,000}{\text{RPM}_{\text{maximum}}} = \frac{120,000}{4000} = 30$$

The selected feedback device must produce 30 or fewer PPR.

The DLC600 can control armature shaft speeds within a 30:1 speed range. Under no circumstances can the DLC600 be expected to control motor speed beyond this speed range.

Select Switches

Access the switches from the rear of the DLC600 case. Using a screwdriver, loosen the two screws that attach the nameplate to the case. The switches are visible when the nameplate is removed.

Line Voltage Switch (SW501)

The slide switch on the left rear of the DLC600 (Figure 7) is the voltage switch. Set this switch to the left position for 115 VAC input or to the right for 230 VAC input.




Figure 7. SW501 - Line Voltage Switch

Encoder Power Supply Voltage (SW502, DIP Switch 1)

DIP switch 1 selects the supply voltage for an external encoder (Figure 8). Set to OFF for +5 VDC source or to ON for a +12 VDC source. If using a device that does not need to be powered by the DLC600, set to OFF.

The power supply voltage has a maximum current of 10 mA.




Figure 8. SW502, DIP Switch 1 - Encoder Power Supply Voltage

Feedback Device Selection (SW502, DIP Switches 2 & 3)

DIP switches 2 and 3 are for feedback device selection (Figure 9). If using an optical pickup, hall sensor, proximity switch, or an open-collector transducer, set DIP switch 2 to ON and 3 to OFF. If a magnetic pickup is used, set DIP switch 2 to OFF and 3 to ON.




Figure 9. SW502, DIP Switches 2 and 3 - Feedback Device Selection

Reference Signal Selection (SW502, DIP Switches 4 & 5)

DIP switches 4 and 5 are for reference signal selection (Figure 10). If an internal reference signal is used (normal operation), set DIP switch 4 to OFF and 5 to ON. If an external reference signal is used, set DIP switch 4 to ON and 5 to OFF. The external reference is only used in Leader-Follower applications.




Figure 10. SW502, DIP Switches 4 and 5 - Reference Signal Selection

Section 5. Calibration



Dangerous voltages exist on the DLC600 when it is powered. When possible, disconnect the voltage input from the DLC600 before adjusting the trim pots. If the trim pots must be adjusted with power applied, use insulated tools and the appropriate personal protection equipment. **BE ALERT.** High voltages can cause serious or fatal injury.

All adjustments increase with CW rotation, and decrease with CCW rotation. Use a non-metallic screwdriver for calibration. Each trim pot is identified on the printed circuit board.

Calibrate the drive for use with the DLC600. The purpose is to optimize the response on the drive to the DLC600 signal and to minimize any tendency by the drive to independently attempt to regulate motor speed. The following are the drive's trim pot settings:

Minimum Speed: CCW (motor stopped)

Maximum Speed: CW (maximum voltage setting)

Acceleration: CCW (fastest acceleration)

Deceleration: CCW (fastest deceleration)

IR Compensation: CCW (minimum regulation)

Current Limit: 150% of motor current rating.

MIN and MAX

1. Set the MIN and MAX trim pots full CCW.
2. Set the motor speed to zero using the following steps.
 - A. Press ENTER once. The most significant digit (the leftmost numeral) will blink.
 - B. Use the UP and DOWN pushbuttons to set this digit to zero.
 - C. Press ENTER once. The second digit from the left will blink.
 - D. Use the UP and DOWN pushbuttons to set this digit to zero.
 - E. Press ENTER once. The third digit from the left will blink.
 - F. Use the UP and DOWN pushbuttons to set this digit to zero.
 - G. Press ENTER once. The least significant digit (the rightmost numeral) will blink.
 - H. Use the UP and DOWN pushbuttons to set this digit to zero.
 - I. Press ENTER once to return to operating mode.
3. Adjust the MIN trim pot CW until the motor shaft starts to rotate. Slowly adjust the MIN trim pot CCW until the motor just stops.
4. Set the DLC600 speed to 200% of maximum desired motor speed as outlined in step 2 above.
5. Adjust the MAX trim pot until the motor is running at 120% of desired motor speed.
6. Check that the MIN trim pot does not need to be readjusted after completing this procedure by repeating steps 2 and 3 as necessary.

Section 7. Programming

Calculating Parameters

Five parameters must be known before programming the DLC600. These parameters are speed scaling factor, load response, display scaling factor, gate time, and decimal point location. All parameters must be programmed into the DLC600 except for the gate time.

Speed Scaling Factor

The speed scaling factor (SSF) correlates the digital speed set at the DLC600 with the speed (in RPM) desired at the feedback shaft. The SSF equation is

$$SSF = \frac{(\text{Speed Entry})(3000)}{(\text{Shaft RPM})(PPR)}$$

where,

Speed Entry = speed programmed into the DLC600. This speed entry may be numerically different than the actual shaft RPM (for example, feet per minute, gallons per minute, inches per second, etc.)

Shaft RPM = the speed (in RPM) of the shaft where the feedback device is mounted.

PPR = the number of pulses per revolution generated by the feedback device.

The SSF range is 3 through 9999 and the factory setting is 50.

Load Response Number

The load response number determines how fast the DLC600 responds to load changes. The higher the load response number, the faster the DLC600 will respond.

The load response number range is 0 through 99. The factory setting is 25.

Display Scaling Factor

The display scaling factor (SSF) correlates the speed displayed by the DLC600 with the speed at the feedback shaft. The DSF equation is

$$SSF = \frac{(\text{Speed Display})(3000)}{(\text{Shaft RPM})(PPR)}$$

where,

Speed Display = speed displayed by the DLC600. This speed entry may be numerically different than the actual shaft RPM (for example, feet per minute, gallons per minute, inches per second, etc.)

Shaft RPM = the speed (in RPM) of the shaft where the feedback device is mounted.

PPR = the number of pulses per revolution generated by the feedback device.

The DSF range is 3 through 9999 and the factory setting is 50.

Gate Time

The display scaling factor determines the gate time (the time between successive display updates). The recommended gate time range is 0.5 - 3 seconds. The gate time equation is shown below:

$$\text{Gate Time} = \frac{\text{DSF}}{25}$$

Decimal Point Location

The decimal point location number fixes the decimal point within the DLC600 display. The DLC600 may be set for no decimal point, or for a decimal point in the tenths, hundredths, or thousandths position. The factory setting is for no decimal point.

Entering the Programming Mode

1. Press and hold the ENTER pushbutton (labeled E) while applying AC power to the DLC600 only. Do not apply power to the drive.
2. Release the ENTER pushbutton after AC power is applied.

You have entered the programming mode when the decimal point appears on the display in the lower right-hand corner. If no decimal points appear or if any number is flashing, remove AC power and repeat steps 1 and 2.

Viewing the Programming Screens

The programming screens are identified by the position of the decimal point displayed; one decimal indicates speed scaling factor mode, two decimals indicates load response number mode, three decimals indicates display scaling factor mode, and four decimals indicate decimal point location.

The DLC600 factory settings are:

Speed Scaling Factor = 50	Display: 0 0 5 0.
Load Response = 25	Display: 0 0 2.5.
Display Scaling Factor = 50	Display: 0 0.5.0.
Decimal Point Location = None	Display: 0.0.0.0.

Entering the Calculated Program Parameters

1. Press ENTER until the decimal point is displayed in the lower right corner (e.g. 1 2 3 4.).
2. Press the UP and DOWN pushbuttons until you reach the desired speed scaling factor.
3. Press ENTER until there are two decimal points displayed (e.g. 1 2 3.4.).
4. Press the UP and DOWN pushbuttons until you reach the desired load response number.
5. Press ENTER until there are three decimal points displayed (e.g. 1 2.3.4.)
6. Press the UP and DOWN pushbuttons until you reach the desired display scaling factor.
7. Press ENTER until there are four decimal points displayed (e.g. 1.2.3.4.).
8. Press the UP and DOWN pushbuttons until the desired decimal location is displayed.

0.000 = no decimal (e.g. 1 2 3 4)

0.001 = tenths (e.g. 1 2 3.4)

0.002 = hundredths (e.g. 1 2 .3 4)

0.003 = thousandths (e.g. 1.2 3 4)

Save the Program Settings and Exit the Programming Mode

1. Press and hold the ENTER pushbutton.
2. Press the UP pushbutton to exit the program mode.

Repeat steps 1 and 2 if you are still in the programming mode. If a numeral is flashing, press ENTER repeatedly until all digits stop flashing.

Set the Speed

1. Press ENTER once. The most significant digit will blink.
2. Use the UP and DOWN pushbuttons to set the desired value for this digit.
3. Press ENTER once. The second digit from the left will blink.
4. Use the UP and DOWN pushbuttons to set the desired value for this digit.
5. Press ENTER once. The third digit from the left will blink.
6. Use the UP and DOWN pushbuttons to set the desired value for this digit.
7. Press ENTER once The least significant digit will blink.
8. Use the UP and DOWN pushbuttons to set the desired value for this digit.
9. Press ENTER once to return to the operating mode.
10. Remove power to the DLC600.
11. Reconnect the drive and apply power to the DLC600 and drive simultaneously.
12. The motor will accelerate to the set speed.
13. To change the set speed, repeat steps 1 - 9.

Programming Examples

Example 1

An application uses a 30 tooth magnetic pickup mounted on a motor shaft. The application requires that the motor speed and display be equal to the speed entry. Calculate the program parameters.

Solution:

PPR = 30 (given in example)

Shaft RPM = 100 (arbitrarily chosen)

Speed Entry = 100 (same as Shaft RPM)

Speed Display = 100 (same as Shaft RPM)

$$SSF = \frac{(\text{Speed Entry})(3000)}{(\text{Shaft RPM})(PPR)} = \frac{(100)(3000)}{(100)(30)} = 100$$

$$DSF = \frac{(\text{Speed Display})(3000)}{(\text{Shaft RPM})(PPR)} = \frac{(100)(3000)}{(100)(30)} = 100$$

$$\text{Gate Time} = \frac{DSF}{50} = \frac{100}{50} = 2 \text{ seconds}$$

Example 2

An application uses a 60 tooth magnetic pickup mounted on a motor shaft. The application requires that the motor speed and display be equal to the speed entry. Calculate the program parameters.

Solution:

PPR = 60 (given in example)

Shaft RPM = 100 (arbitrarily chosen)

Speed Entry = 100 (same as Shaft RPM)

Speed Display = 100 (same as Shaft RPM)

$$SSF = \frac{(\text{Speed Entry})(3000)}{(\text{Shaft RPM})(\text{PPR})} = \frac{(100)(3000)}{(100)(60)} = 50$$

$$DSF = \frac{(\text{Speed Display})(3000)}{(\text{Shaft RPM})(\text{PPR})} = \frac{(100)(3000)}{(100)(60)} = 50$$

$$\text{Gate Time} = \frac{DSF}{50} = \frac{50}{50} = 1 \text{ second}$$

The PPR in this example is larger than the PPR in Example 1. Increasing the PPR decreases the speed scaling factor, display scaling factor, and the game time.

Example 3

An application uses a 30 tooth magnetic pickup mounted on a motor shaft that is part of an exercise treadmill. The pulley is driving a belt that has a radius of 4 inches. The applications requires the user to enter the speed in miles per hour, and the display to read in miles per hour. Calculate the program parameters.

Solution:

PPR = 30 (given in example)

Speed Entry = 10 (for 10 miles per hour, arbitrarily chosen)

Speed Display = 10 (same as Speed Entry)

Shaft RPM = Need to calculate by converting 10 miles per hour into RPMs.

NOTE: Circumference of pulley = $2\pi * \text{radius} = 2\pi * 4 \text{ inches}$

$$10 \frac{\text{miles}}{\text{hour}} = \frac{10 \text{ miles}}{1 \text{ hour}} \times \frac{5280 \text{ feet}}{1 \text{ mile}} \times \frac{12 \text{ inches}}{1 \text{ foot}} \times \frac{1 \text{ revolution}}{2\pi * (4) \text{ inches}} \times \frac{1 \text{ hour}}{60 \text{ minutes}} =$$

$$420.17 \frac{\text{revolutions}}{\text{minute}} = 420.17 \text{ RPM}$$

$$\text{SSF} = \frac{(\text{Speed Entry})(3000)}{(\text{Shaft RPM})(\text{PPR})} = \frac{(10)(3000)}{(420.17)(30)} = 2.379 \approx 2$$

$$\text{DSF} = \frac{(\text{Speed Display})(3000)}{(\text{Shaft RPM})(\text{PPR})} = \frac{(10)(3000)}{(420.17)(30)} = 2.379 \approx 2$$

$$\text{Gate Time} = \frac{\text{DSF}}{50} = \frac{2}{50} = 0.04 \text{ seconds}$$

The gate time is too small. You may introduce a decimal point on the display.

The user could enter 100 which would appear as 10.0 miles per hour the display. The speed entry and speed display numbers in the formula now become 100. Recalculating parameters.

$$\text{SSF} = \frac{(\text{Speed Entry})(3000)}{(\text{Shaft RPM})(\text{PPR})} = \frac{(100)(3000)}{(420.17)(30)} = 23.79 \approx 24$$

$$\text{DSF} = \frac{(\text{Speed Display})(3000)}{(\text{Shaft RPM})(\text{PPR})} = \frac{(100)(3000)}{(420.17)(30)} = 23.79 \approx 24$$

$$\text{Gate Time} = \frac{\text{DSF}}{50} = \frac{24}{50} = 0.48 \text{ seconds} \approx 0.5 \text{ seconds}$$

Adding a decimal point widens the input range (the range of settings from 0 to maximum), increases the gate time, and decreases the rounding error to the nearest digit in the first calculation of the SSF and DSF. The DLC600 has a gate time range of 0.5 - 3 seconds.

Example 4

An application uses a 30 tooth magnetic pickup mounted on the high speed shaft of a gear motor. The gear ratio is 40:1 and the high speed RPM is 1800. The user will enter the speed of the geared shaft. The gear shaft RPM is what will be displayed as well.

Solution:

PPR = 30 (given in example)

Speed Entry = 10 (for 10 RPM, arbitrarily chosen)

Speed Display = 10 (same as Speed Entry)

Shaft RPM = Speed of high speed shaft. If geared shafting is running at 10 RPMs (Speed Entry), then high speed shaft is running at 400 RPMs (10 x 40:1 Gear Ratio).

$$SSF = \frac{(\text{Speed Entry})(3000)}{(\text{Shaft RPM})(PPR)} = \frac{(10)(3000)}{(400)(30)} = 2.5 \approx 3$$

$$DSF = \frac{(\text{Speed Display})(3000)}{(\text{Shaft RPM})(PPR)} = \frac{(10)(3000)}{(400)(30)} = 2.5 \approx 3$$

$$\text{Gate Time} = \frac{DSF}{50} = \frac{2.5}{50} = 0.05 \text{ seconds}$$

The gate time is not within the DLC600's range of 0.5 - 3 seconds. There is also a significant error (20%) in rounding 2.5 to 3. Introduce a decimal point and recalculate the program parameters. Since the user will enter 10.0 for 10 RPM, the speed entry is now 100. The speed display is also 100.

Recalculating the program parameters:

$$SSF = \frac{(\text{Speed Entry})(3000)}{(\text{Shaft RPM})(PPR)} = \frac{(100)(3000)}{(400)(30)} = 25$$

$$DSF = \frac{(\text{Speed Display})(3000)}{(\text{Shaft RPM})(PPR)} = \frac{(100)(3000)}{(400)(30)} = 25$$

$$\text{Gate Time} = \frac{DSF}{50} = \frac{25}{50} = 0.5 \text{ seconds}$$

This is much more acceptable. Note that there is no error due to rounding here because the SSF and DSF came out to be whole numbers.

Section 8. Leader-Follower Applications

The DLC600 can be used to follow an external frequency for leader-follower applications. The external frequency must be a 5 VDC CMOS logic-level signal or an open-collector NPN transistor. The external frequency must be within the range of 10 - 3000 Hz for correct operation.

The product of the external frequency and the set speed on the DLC600 must not exceed 500 kHz. This will limit the speed set value to 5000 or less ($500,000 / 10 = 50,000$; however, the DLC600 only uses 4 digits. Thus, the maximum is 5000).

The display can be set to read the speed ratio, actual speed in RPM, or a process value (such as feet per second or gallons per minute). Values of 100 and 1000 have the advantage of being easily read as a ratio or percentage of the leader.

To select external reference, set DIP switch 4 of SW502 to ON and DIP switch 5 to OFF. Refer to Figure 10 on page 16.

Leader-Follower Example Using A Leader Encoder

In this example, the DLC600 receives a signal from an encoder on a lead motor. The DLC600 then controls a follower motor at 100% of the lead motor's speed.

Assume the following conditions exist:

- The lead motor's maximum speed is 1800 RPM.
- The resolution of the encoder on the lead motor is 60 lines.
- The magnetic pickup on the follower motor has 30 teeth.

NOTE: For this example, if the set speed is 100, the motor will follow at 100% of the lead motor's speed. If the set speed is 50, the motor will follow at 50% of the lead motor's speed. The DLC600 will display the follower speed in RPM.

Step 1. Calculate the leader frequency (FR) using the following formula:

$$FR = \frac{\text{Maximum RPM of lead motor} * \text{PPR of lead feedback}}{60}$$

Thus,

$$FR = \frac{1800 * 60}{60} = 1800 \text{ Hz.}$$

Step 2. Calculate the follower frequency (FM) using the following formula:

$$FM = \frac{\text{Maximum RPM of follower motor} * \text{PPR of follower feedback}}{60}$$

Thus,

$$FM = \frac{1800 * 30}{60} = 900 \text{ Hz.}$$

Having derived FR and FM, you can now calculate the speed scale factor.

Step 3. Calculate the SSF

Program the speed scale factor (SSF) per the following formula:

$$SSF = \frac{FR * \text{Set Speed}}{FM}$$

where,

FR = FR calculated in step 1.

FM = FM calculated in step 2.

Set Speed = Desired leader/follower speed ratio, expressed as a percentage. For example, if you want the follower to run at half the speed of the leader, the set speed is 50. For this example, the set speed is 100 (i.e. match the leader speed).

Thus,

$$SSF = \frac{FR * \text{Set Speed}}{FM} = \frac{1800 * 100}{900} = 200$$

The speed scale factor is 200.




Figure 11. Leader-Follower Connections with a Leader Encoder

Leader-Follower Example Using Two DLC600's



The DLC600 may drive only one follower using this method.

In this example, the follower DLC600 receives a signal from a leader DLC600. The follower DLC600 then controls a follower motor at 100% of the lead motor's speed.

Leader-Follower Connections

Use 14 - 28 AWG wire to connect the leader and follower DLC600's. Connect SO502 terminal FO- on the leader DLC600 to the C terminal on the follower DLC600. Connect SO502 terminal FO+ on the leader DLC600 to the Fin terminal on the follower DLC600. Refer to Figure 12 on page 38.

If the leads are longer than 12 inches (30 cm), it is recommended to use shielded leads. If shielding is not practical, twist all logic leads with themselves to minimize induced noise.

Programming the Leader

Program the leader DLC600 to reflect the following conditions. Refer to page 19 for instructions on programming a DLC600.

1. Set the speed scale factor (SSF) to 100. Although the SSF may be set to any value, the frequency output via FO+ and FO- is always the equivalent of 50% of set speed. Thus, setting the SSF to 100 makes it easier to monitor the signal sent to the follower DLC600.
2. Set the display scale factor (DSF) to 100. Like the SSF, the DSF may be set to any value; however, a setting of 100 makes it easier to monitor the system.

Programming the Follower

Program the follower DLC600 as follows;

1. Calculate the follower reference frequency (FR) using the following formula:

$$FR = \frac{25 * \text{Lead Motor Speed in RPM}}{\text{SSF of Lead DLC600}}$$

In this example, assume the lead motor speed is 1800 RPM. The leader SSF in this example is 100.

Thus,

$$FR = \frac{25 * \text{Lead Motor Speed in RPM}}{\text{SSF of Lead DLC600}} = \frac{25 * 1800}{100} = 450 \text{ Hz}$$

2. Calculate the follower motor feedback frequency (FM) using the following formula:

FM =

In this example, assume the lead motor speed is 1800 RPM. The leader SSF in this example is 100.

Thus,

$$FM = \frac{\text{Follower Motor Speed in RPM} * \text{PPR of Follower Feedback}}{60}$$

As noted earlier, assume the motor speed is 1800 RPM. The follower feedback is 30 PPR in this example.

$$\text{Thus, } FM = \frac{1800 * 30}{60} = 900 \text{ Hz}$$

3. Calculate the speed scale factor SSF using the following formula:

$$\text{SSF} = \frac{\text{FR} * \text{Follower Speed as a \% of Leader Speed}}{\text{FM}}$$

Using the FR from step 1, the FM from step 2, and using a set speed of 100% for this example...

$$\text{SSF} = \frac{450 * 100}{900} = 50$$

The speed scale factor is 50. Enter this value as the SSF on the follower DLC600.

4. It is recommended that you set the DSF of the follower DLC600 to 100. Although any you can set whatever DSF value you'd like, setting it to 100 removes the need to correlate the DSF value with system speed.

5. Enter the follower speed setting as a percentage of the lead motor speed. For example, if you want the follower to run at the same speed as the leader, the speed setting would be 100. To run the follower at half the leader speed, enter 50, or 33 to run at 33%, etc. Refer to page 24 for instructions on entering the set speed.




Figure 12. Leader-Follower Connections with two DLC600s

Section 9. Troubleshooting

The motor will not run.

1. The connections from the DLC600 to the drive, or the drive to the motor, may not be wired correctly. Check the connections from the DLC600 to the drive and from the drive to the motor.
2. The drive may be defective. Disconnect the DLC600 from the drive. Connect a speed adjust potentiometer to the drive and see if the drive runs the motor properly.
3. The motor may be defective. Test the system with another motor.

The motor will not lock into speed.

1. The load response number may be too low (if the oscillation is gradual) or too high (if the oscillation is rapid).
2. The drive may be incorrectly calibrated. Check that the acceleration, deceleration, and IR Comp trim pots are at their minimum settings.
3. If a magnetic pickup is used, extensive runout may cause an interruption in the feedback pulse train. Check that the pickup's sensing tip is directly over the center of the gear teeth. The gap between the sensing tip and the gear tip should be no greater than 0.010 inches.
4. Electrical noise may cause the DLC600 to attempt corrections that are not justified. Check the continuity and shielding of the pickup leads.
5. Rapid shifts in load may be pulling the motor out of its set speed. Consider using a regenerative drive with the DLC600.

The motor is running at a fixed difference below set speed.

1. There may be a 60 Hz signal riding on the pickup leads. Check that the pickup leads are run in their own conduit and that all connections are secure. For long paths, these leads must be shielded, and properly grounded at the DLC600 end.

The motor is running at a fixed difference below set speed.

1. There may be an electromechanical defect in the pickup or sensor, or a break in the pickup or sensor leads. Check that the pickup or sensor is working properly, and that there are no breaks in the pickup or sensor leads.

2. The pickup may not be properly aligned over the gear, causing inaccurate feedback information. Check the alignment of the pickup over the gear.

Unconditional Warranty

A. Warranty

Minarik Drives warrants that its products will be free from defects in workmanship and material for twelve (12) months or 3000 hours, whichever comes first, from date of manufacture thereof. Within this warranty period, Minarik Drives will repair or replace, at its sole discretion, such products that are returned to Minarik Drives, 14300 De La Tour Drive, South Beloit, Illinois 61080 USA.

This warranty applies only to standard catalog products, and does not apply to specials. Any returns of special controls will be evaluated on a case-by-case basis. Minarik Drives is not responsible for removal, installation, or any other incidental expenses incurred in shipping the product to and from the repair point.

B. Disclaimer

The provisions of Paragraph A are Minarik Drives's sole obligation and exclude all other warranties of merchantability for use, expressed or implied. Minarik Drives further disclaims any responsibility whatsoever to the customer or to any other person for injury to the person or damage or loss of property of value caused by any product that has been subject to misuse, negligence, or accident, or misapplied or modified by unauthorized persons or improperly installed.

C. Limitations of Liability

In the event of any claim for breach of any of Minarik Drives's obligations, whether expressed or implied, and particularly of any other claim or breach of warranty contained in Paragraph A, or of any other warranties, expressed or implied, or claim of liability that might, despite Paragraph B, be decided against Minarik Drives by lawful authority, Minarik Drives shall under no circumstances be liable for any consequential damages, losses, or expenses arising in connection with the use of, or inability to use, Minarik Drives's product for any purpose whatsoever.

An adjustment made under warranty does not void the warranty, nor does it imply an extension of the original 12-month warranty period. Products serviced and/or parts replaced on a no-charge basis during the warranty period carry the unexpired portion of the original warranty only.

If for any reason any of the foregoing provisions shall be ineffective, Minarik Drives's liability for damages arising out of its manufacture or sale of equipment, or use thereof, whether such liability is based on warranty, contract, negligence, strict liability in tort, or otherwise, shall not in any event exceed the full purchase price of such equipment.

Any action against Minarik Drives based upon any liability or obligation arising hereunder or under any law applicable to the sale of equipment or the use thereof, must be commenced within one year after the cause of such action arises.



www.minarikdrives.com
14300 DE LA TOUR DRIVE
SOUTH BELOIT, IL 61080
(800) MINARIK

250-0316 Rev 5