



CONTINUOUS BELT IR BELT FURNACE

TP Solar Model TF-618 Owner's Manual

Revision 0



MODEL: TF-618

SERIAL NUMBER: 2015260

FACTORY ORDER NUMBER: 15-004

Infrared Furnace Setup, Operation, Theory & Troubleshooting Guide

This Owner's Manual contains product information specific to the newly installed equipment and software. In addition, this manual contains information regarding features and options which may or may not be included in your furnace system.

Continuous Belt IR Furnace

Owner's Manual

Rev. 0

Model: TF-618

Serial Number: 1506151401

Part No. 15-004 - 676-110000-01 CD

Part No. 15-004 - 676-110000-02 Loose Leaf

Edited by: J. Clark, S. Barber, C. Roode

Published by:

Lochaber Cornwall, Inc., 675 North Eckhoff Street, Ste D, Orange, California 92868 USA

714.935.0302 fax 714.935.9809

www.LCIfurnaces.com

service@furnacepros.com

Copyright ©2016 by Lochaber Cornwall, Inc., Orange, California, USA. All rights reserved.

Manufactured in the United States of America.

Limit of Liability/Disclaimer of Warranty. The information in this document is subject to change without notice. The statements, configurations, technical data and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. The publisher and author make no representation or warranties with respect to the accuracy or completeness of the contents of this work and specifically disclaim all warranties including without limitation warranties of fitness for a particular purpose. No warranty may be created or extended by sales or promotional materials. The advice and strategies contained herein may not be suitable for every situation. If professional assistance is required, the services of a competent professional should be sought. Neither the publisher nor the author shall be liable for damages arising herefrom. Warranties for FurnacePros or Lochaber Cornwall, Inc. products and services shall be limited to those are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. THERE ARE NO OTHER WARRANTIES, EXPRESS, STATUTORY OR IMPLIED, INCLUDING THOSE OF MERCHANTABILITY AND OF FITNESS FOR PARTICULAR PURPOSE, NOR ANY AFFIRMATION OF FACT NOR REPRESENTATION WHICH EXTENDS BEYOND THE DESCRIPTION OF THE FACE HEREOF.

Users must take full responsibility for their application of any products, recommendations, processes or procedures mentioned in this document. Lochaber Cornwall shall not be liable for technical or editorial errors or omissions contained herein. The information in this document is proprietary to Lochaber Cornwall, Inc.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical without express written permission from the publisher.

For information on parts, service and aftermarket products and reconditioned furnaces and to obtain technical support please contact FurnacePros Aftermarket Services at +1.714.935.0302.

Trademarks. LCI, LCI Furnaces, Lochaber Cornwall logo and shield and FurnacePros logo are trademarks or registered trademarks of Lochaber Cornwall, Inc. TPS, TPSI and TP Solar are trademarks of TP Solar, Inc. All other trademarks are the property of their respective owners.

TABLE OF REVISIONS

Rev	Sections	Description	Date
0	All	Initial Release	4/10/2016