

## FURNACE EQUIPMENT

Description of the SMD-615 infrared furnace basic thermal process elements, standard and optional hardware and their functions. Refer to section 0.6 for optional equipment description and operation.

### 0.1 Furnace Description

The SMD-615 is a computer controlled near-infrared, conveyor belt furnace for laboratory and production thermal processing in the range of 100-600 °C in a controlled atmosphere, free of outside contamination. Your furnace is configured for a maximum 600 °C temperature operation. Process gas may be CDA, N<sub>2</sub> and/or another inert gas. Dual gas furnaces may use Air with Nitrogen in the furnace process zones; or Nitrogen and a second gas such as Forming Gas (pre-mixed N<sub>2</sub>/H<sub>2</sub>) or another type of reducing gas injected into the heating chamber.




Figure 0-1 SMD-615 IR Furnace Front Elevation

The SMD-615 furnace transports product on a 380 mm (15-inch) wide belt. In the standard design the chamber clearance above the belt is 50 mm (2 inches). Optionally the furnace can be ordered with 25 mm (1-inch) or 100 mm (4-inch) vertical clearance above belt. SMD-615 furnaces feature a hermetically sealed heating chamber permitting control of the furnace chamber process environment. Baffle sections before and after the heating section contain curtains that hang down to just above the belt to further isolate the furnace chamber from the room atmosphere and from the cooling section.

The SMD-615 can process substrates, wafers, PCBs, metal, ceramic, glass or polycarbonate parts for electronic package sealing, thermo-setting polymer curing, reflow soldering, copper and hybrid/thick film firing, brazing, tempering and metal sintering applications, or almost any kind of general thermal processing requiring precision temperature control in a controlled atmosphere environment.

The SMD-615 can also be used for precise curing of coatings on optical lenses, advanced thin film crystalline silicon, cadmium telluride (CdTe alloys) and certain copper indium diselenide (CIS-alloys) as well as many dental lab and production applications.

0.2 Furnace Views



Figure 0-2 Typical IR Furnace Rear Elevation



Figure 0-3 Entrance Elevation



Figure 0-4 Exit Elevation




Figure 0-5 Front, Panels Off



Figure 0-6 Rear, Lower Panels Off



Figure 0-7 Front Entrance view with optional Entrance Extension




Figure 0-8 Front Exit view with optional Exit Extension and optional SENSLAS Product Alert

## 0.3 Furnace Elements

### 0.3.1 Furnace Arrangement

During furnace operation, parts are carried from the load station through the heating and cooling sections of the furnace to the unload station on a 380 mm (15-inch) wide belt driven by an adjustable speed motor. Maximum vertical parts clearance inside the standard furnace is 50 mm (2 inches).




Figure 0-9 Process Sections

**Process atmosphere** is controlled much like a clean room: pressurized gas is pushed through the heating chamber insulated walls providing pre-heated, laminar flow for a uniform, stable atmosphere.

**Zones.** The heating chamber is divided into zones separated by insulating dividers so that adjacent zones can maintain different setpoint temperatures, if required. Control starts with K-type thermocouples in each zone quickly sensing changing conditions and feeding these signals to the PLC which communicates with the furnace computer. The furnace software PID loop algorithms control arrays of IR quartz heating lamps inside the heating chamber so as to maintain the desired temperature setpoint in each zone.

**Product cooling** is by radiant cooling and CDA or N<sub>2</sub> gas convective cooling in an enclosed tunnel, with exterior fan heat removal.

### 0.3.2 Heat Transfer Methods

Transfer of heat in the furnace is by three different methods: Radiation, Convection and Conduction. In order of their contribution to heating the product, these methods are:

#### A. Radiation

The furnace lamps emit infrared electromagnetic waves which, when striking and absorbed by product on the belt, cause its temperature to rise. “Heat lamps” and microwave ovens work in a similar manner and it is also the way the sun heats the Earth. The infrared radiation does not directly heat the process gas within the furnace.

#### B. Convection

During operation, lamp radiation heats the chamber top, bottom and side wall insulation. As the process gas enters the furnace through the porous ceramic insulation, it is heated to near the setpoint temperature of the zone. This flow of heated gas transfers heat to the product on the belt. Hair dryers and home forced air heating function in the same fashion.

#### C. Conduction

Lamp radiation heats the transport belt which becomes a heat source for the product supported on the belt. Electric stoves and hot plates heat in this way.

### 0.3.3 Controlled Atmosphere

LCI furnaces are equipped with the ability to supply constant streams of a supplied process gas. This feature allows the user to reduce product oxidation or contamination, remove process effluents or reduce other potentially negative effects of ambient air at high temperatures.



## Section 0

A controlled atmosphere also helps establish higher consistency in thermal processes. When a product travels through the process section, slight changes in the atmospheric conditions in a non-controlled atmosphere environment can affect the stability and consistency of the product temperature profile.

### 0.3.4 Hermetically Sealed Systems

For most furnace systems, the lamps ends are enclosed in plenums. Gas fed to the plenums keeps the lamps cool and prolongs the life of the lamp and improves lamp IR performance. Balancing the furnace gas inflows and outflows enables the furnace to maintain a hermetic seal. While not air-tight, a hermetic seal resists the mixing of the outside atmosphere with the furnace atmosphere by maintaining a higher pressure inside the furnace chamber.

### 0.3.5 Furnace Process Equipment

The furnace process equipment includes an entrance baffle with an eductor equipped exhaust stack, a heating chamber, a transition tunnel with exhaust stack(s) between the heating and cooling sections with rapid cool tunnel configured for 50mm (2-inch) product height (PH2) followed by a variable fan-cooled section, arranged as shown in Figure 0-10.




Figure 0-10 6-Zone SMD Furnace Internals

Together, the individual sections function as a unit to provide a carefully controlled gas atmosphere, precise temperature profile and two-stage controlled atmosphere cooling.

### 0.3.6 Load Station (LOAD)

Located immediately before the furnace entrance, the Load station consists of two (2) horizontal stainless steel surfaces 448 mm (17.625 inches) long x 250 mm (9.875 inches) wide positioned on either side of the belt. The Load station provides a convenient area for handling product and for holding profiling equipment. Extensions in multiples of 380 mm (15 inches) can be added to increase the length of the Load station.

### 0.3.7 Entrance Baffle & Exhaust Stack (BE)

The entrance baffle isolates the heating section from the ambient air outside the furnace entrance. It is housed in a welded stainless steel shell lined with ceramic fiber insulation. An  $N_2$  gas curtain with a series of hanging stainless steel baffle plates serves to act as a thermal barrier as well as purge the baffle and help prevent ambient air from entering the furnace. Owner can stipulate baffle clearance of 6 mm to 40 mm (0.25 to 1.5 inches) above the belt (or eliminate entirely). Adjust gas flow to the ENTRANCE BAFFLE flowmeter to isolate Zone 1 from room atmosphere.

A venturi-assisted exhaust stack, or “eductor”, draws furnace gases out of the furnace. Before exhausting via the stack, the process gas passes over a removable drip tray to collect exhaust condensation and prevent it from falling into the baffle section and contaminating the product. The eductor pulls 15 times its process gas flow from the furnace. Adjust gas flow to the ENTRANCE EDUCTOR flowmeter to balance the furnace gas outflow with the gas inflow.

### 0.3.8 Heating Chamber

The two (2) furnace chambers are similar in construction to the entrance baffle and are hermetically sealed with plenum covers over the lamp ends. Inside this section, arrays of tungsten filament quartz heating lamp tubes located above and below the belt, generate intense near-wave (sometimes called “short-wave”) infrared light with a color temperature of 2500 K (peak wave length of 1.16  $\mu\text{m}$ ). These lamps are very efficient heaters with very fast response times, producing up to 900 W per lamp at full power and capable of heating the furnace chamber to a state of equilibrium within minutes.

**Lamp Arrangement.** The lamps are arranged symmetrically above and below the belt. The top and bottom lamps may be used independently or together to configure the best possible heat transfer mode for each individual process. **Table 0-1 Furnace Arrangement** shows the distribution of lamps and available power in each zone. See 802-101500 Power and Current datasheet in Section 5 for more information of the distribution of lamps and available power in each zone.

<b>Table 0-1 Furnace Arrangement</b>					
<b>Zone</b>	<b>Zone Length (mm)</b>	<b># of Lamps Top / Btm</b>	<b>Lamp Spacing (mm)</b>	<b>Max. Available Zone Power* (W) 208 – 480 Vac</b>	<b>Max. Available Zone Power (W) 415 Vac</b>
1	254	6 / 6	30	5500 - 18000	15900
2	254	6 / 6	30	2900 – 10600	8500
3	254	6 / 6	30	2900 - 10600	8500
4	254	6 / 6	30	2900 - 10600	8500
5	254	6 / 6	30	2900 - 10600	8500
6	254	6 / 6	30	5500 - 18000	15900

\*Depends on line voltage.

**Power Configurations.** The SMD-615 furnace is wired full power in the first and last zones and half power in all other zones. Zones 1 and 6 are wired with two (2) parallel strings, each consisting of two (2) lamps in series. Zone 3-5 are wired with three (3) parallel strings, each string consisting of three (2) lamps in series. This model will perform well throughout the design temperature range of the furnace (100-600 °C). Lamps within the furnace are arranged as shown in Table 0-2.

<b>Table 0-2 Furnace Lamp Wiring Configuration</b>				
	<b>Zone</b>	<b>Standard Configuration</b>		<b>Total Number of Lamps</b>
		<b>Strings Top/Btm</b>	<b>Lamps per String Top/Btm</b>	
<b>Chamber 1</b>	1	2	3	12
	2	3	2	12
	3	3	2	12
<b>Chamber 2</b>	4	3	2	12
	5	3	2	12
	6	2	3	12

**Zones.** Each heating chamber is partitioned into 3 separate zones using ceramic fiber dividers. The dividers are designed with the smallest possible opening consistent with the parts clearance specifications. This partitioning assures very high thermal isolation between zones. Although the heating profile across the belt is extremely uniform, heat losses through the furnace side walls and at the belt edge supports produce a temperature drop near the edges of the transport belt. Away from the extreme edges of the belt, overall temperature uniformity across the belt is normally better than  $\pm 3$  °C. Edge heaters can be used to improve the temperature evenness across the belt.

**Temperature Measurement.** Inside the furnace chamber, at the top center of each zone a type K thermocouple measures the temperature in that zone and provides feedback to each respective zone PID controller to determine the amount of power necessary to maintain setpoint temperatures. However useful these thermocouples are for controlling the temperature in each zone, the actual part is exposed to three heat transfer methods. As with any furnace, the most accurate way to determine what temperature product on the belt actually sees from these three methods of heating is to profile the furnace with a thermocouple placed directly on the product surface.

## Section 0

**Chamber Process Gas.** Process gas (CDA, N<sub>2</sub>, FG or other gas) is preheated before reaching the furnace interior by allowing it to permeate through the hot porous ceramic fiber insulation. This method of gas distribution does not affect the temperature profile and helps keep the furnace interior clean.

### 0.3.9 Exit Baffle Rapid Cool Transition Tunnel (RCT)

The Exit Baffle consists of a rapid cool transition tunnel with baffles that separate the furnace heating section from the fan cooling section. The transition tunnel is constructed of extruded aircraft aluminum to assure high cooling rates. The rapid cool tunnel is equipped with four (4) top air rakes and two (2) bottom air rakes to provide atmospheric isolation and high rates of cooling. Hanging stainless steel baffle plates act as a thermal barrier and help contain the furnace heating and cooling atmospheres in their respective sections. The RCT is equipped with two (2) exhaust stacks, each with an eductor for removing process gas from the RCT.

Adjust EXIT BAFFLE flowmeter to control product initial temperature drop and to isolate the furnace atmosphere from the cooling section. Adjust EXIT EDUCTOR 1 and EXIT EDUCTOR 2 to balance the RCT environment and exhaust incoming EXIT BAFFLE gas flow. Note: Eductors exhaust 15 times the eductor flow.

### 0.3.10 Fan Cooling Section (FC)

The fan cooling section is an open section with upper and lower fan arrays to cool product before exiting the furnace. Fans mounted above and below the belt transfer heat to the air inside of the furnace cabinet. This cabinet air is then exhausted by cabinet fan through openings in the furnace top cover into the room or for removal by facility exhaust ducting.

Fan air flow rate in this section is controlled by a single turn knob on the Control Console that will increase or decrease fan speed.

### 0.3.11 Unload Station (UNLOAD)

Located immediately after the final cooling stage exit, the Unload station consists of two (2) horizontal stainless steel surfaces 448 mm (17.625 inches) long x 250 mm (9.875 inches) wide positioned on either side of the belt. The Unload station provides a convenient area for placing parts exiting the furnace. Extensions in multiples of 380 mm (15 inches) can be added to increase the length of the Load station.

### 0.3.12 Atmosphere Supply Gas – CDA and Nitrogen

#### A. Furnace Process Gas System

Plant supply process gas must be filtered and regulated to 4.8 bar (70 psi) before the furnace is started to assure consistent clean dry process gas is supplied during furnace operation. An internal gas reservoir with check valve further regulates gas pressure to 15 psi for the belt tensioner.

If the furnace supply gas pressure drops below the set point during operation, the operator should put the furnace into Cool Down. The operator can reset the system to Warm Up when air pressure is again over 70 psig.

Location	Default Setting	
	Plant Process Gas Regulator supply to furnace	65-70 psig
Furnace Regulator (option not supplied)	- psig	- bar
Low Gas Pressure Alarm Switch	60 psig	4.1 bar

See Section 3 for information calibration and service of the pressurized gas (N<sub>2</sub>/CDA) system.

**WARNING: The flowmeters on these furnaces are rated at 70 psi (5 bar) maximum. Operating above 70 psi exposes the operator to possible injury, may cause damage to the furnace internals and insulation and voids the furnace warranty.**



## 0.4 Control System

This control system is comprised of a programmable logic controller (PLC) and computer interface (HMI).



Figure 0-11 Furnace Computer (L) and PLC Controller (R)

### 0.4.1 Computer

The furnace control system uses a high quality computer to manage user interface with the furnace controller and to store recipes. The furnace computer can also be used for profiling and other tasks. See sections 1.3.3 **Computer Connections and Power Options** and 4.5 **Dell Precision T1700** for details of the computer hardware.

### 0.4.2 Controller

The SNAP PAC S1 programmable automation controller provides powerful, real-time control and communication to meet the furnace industrial control, monitoring, and data acquisition needs. The SNAP-PAC-S2 is a compact, industrially hardened controller that can handle multiple control, automation, and data acquisition tasks involving digital and analog control, serial string handling, PID, and enterprise connectivity. Connecting to Opto 22 serial and Ethernet-based I/O systems, the SNAP PAC S1 controller runs the furnace control programs written in Opto 22's PAC Control™ software to monitor and control all critical furnace functions.

The furnace controller continues to manage all aspects of furnace operation even if communication with the furnace computer is lost.



Figure 0-12 PAC-S1 Controller

## Section 0

### 0.4.3 I/O (Input / Output)


The SNAP-PAC-EB2 brain is an I/O and communications processor for the furnace control system. The SNAP-PAC-EB2 provides local intelligence that frees the PAC-S1 controller for supervisory tasks.

As an I/O processor, the SNAP PAC EB2 brain independently handles functions such as latching, thermocouple linearization, watchdog timers, and PID loop control. These functions continue to work in the brain even if communication with the SNAP PAC controller is lost.



### 0.4.4 Furnace Ethernet Network

The furnace computer, SNAP PAC S1 controller and SNAP PAC brains and I/O communicate over standard 10/100 Mbps Ethernet networks and can be attached to existing wired or wireless Ethernet networks. The system includes an industrial Ethernet switch which provide connection to local intelligence and to digital and analog sensors and actuators as well as serial devices. Each if the devices and independent Ethernet ports have separate IP addresses. See Figure 0-14Figure 0-14 Furnace network for typical furnace network configuration



## 0.5 Auxiliary Equipment

### 0.5.1 Cabinet Fans

**Cabinet Fan.** The furnace is equipped with two (2) 10-inch diameter fans mounted on the underside of the top of the furnace cabinet. This fan exhausts heat emitted from the outside of the furnace chamber and cooling tunnel into the room or customer installed exhaust system.

**Cooling System Fans.** The FC cooling system is cooled by fans mounted outside the top and bottom of the tunnel. Cabinet air is forced over and under the belt to transfer heat from the belt and product on the belt. This air is evacuated via the cabinet fans.

### 0.5.2 Low Pressure Alarms (IPS)

Gas Supply Pressure Switches are installed on critical process gas manifolds. These switches are normally closed. They open when proper pressure is present in the process gas supply lines.

The pressure switches are factory set to open when pressure falls below the pressure set points in Table 0-4 for Gas 1 and Gas 2.




Table 0-4 Initial Pressure Alarm Settings				
Manifold	Process Gas	Design Pressure	Pressure Set Points	
Gas 1	Nitrogen or CDA (to eductors)	70 psi (5 bar)	None, not alarmed	
Gas 2	Nitrogen, Forming Gas or other	70 psi (5 bar)	55-60 psi	3.8-4.1 Bar

The pressure switch set points can be adjusted manually. Locate the switch in the process gas supply line. To increase the set point turn the wheel clockwise. Turn the top of the switch counter clockwise to decrease the pressure set point so the alarm will not occur until the pressure drops to a lower point.

### 0.5.3 Belt Travel (LTR)

Standard direction for belt travel is from left to right when facing the furnace Control Console. As an option, the furnace can be configured for right to left operation. This arrangement allows two production furnaces to be easily operated by a single person.




Figure 0-16 Direction of Belt Travel

## Section 0

---

### 0.5.4 Transport Belt

The standard conveyor belt is manufactured of 316 stainless steel as installed on this furnace.

For high temperature applications ( $>450^{\circ}\text{C}$ ) the conveyor belt is a close weave Nichrome-V belt manufactured from high temperature wire comprised of 80% nickel and 20% chromium.

These belts offer fast heat-up times, more uniform operating temperatures and excellent mechanical stability. This belt exhibits minimum shrinkage, growth, sag or distortion in use.

### 0.5.5 Transport Drive Motor

The transport drive motor assembly is typically mounted near the exit of the process section. Depending upon belt width, product mass, product number and belt speed, the motor-sprocket may appear different than the example shown in Figure 0-17 Transport Drive Motor.

### 0.5.6 Universal Transformers

All primary transformers used in the furnace are manufactured specifically for our furnaces. These transformers are 50/60 Hz multi-tap and can be configured to operate the furnace at most commonly available voltages worldwide.



**Figure 0-17 Transport Drive Motor**

## 0.6 Optional Equipment

Features and operation of the most common furnace equipment options that may have been included with the furnace or added later. See Table 0-5 for a summary of featured options. Unshaded items in bold were supplied on the furnace.

<b>AFM</b>	<b>Separate Top/ Bot Flowmeters</b>	<b>GSM</b>	Supply gas mixing system	<b>OSS</b>	<b>Gas sampling system</b>
AFR	Air filter/trap regulator	HO/NHM	H <sub>2</sub> operation N <sub>2</sub> /H <sub>2</sub> mixing	PH1, PH4	25, 100 mm chamber height
AR10	Gas Reservoir	HSK	<b>Handshake Signaling, Up/Dwn</b>	PPG	<b>Pre-purge system, Nitrogen</b>
CB-3	<b>3-phase circuit breaker</b>	IR-E	<b>Interface rollers, small diameter, entr</b>	RTL	Right to Left Belt Travel
CE	CE mark	IR-X	<b>Interface rollers, small diameter, exit</b>	RAID	<b>Furnace Computer with mirroring drives</b>
CXE15	Load station extension	LFI	Line Interference Filter	SENSLAS	<b>Laser product alert system</b>
CXX15	Unload station extension	LT	<b>Light Tower,3-Color Process Ready</b>	SSP	<b>Sample ports</b>
DO	<b>Dual gas operation</b>	MA	Moisture analyzer	UCD	<b>Ultrasonic belt cleaner</b>
EM	<b>Element Monitoring system</b>	OA	<b>Oxygen Analyzer</b>	UPS	<b>Uninterruptable Power Supply</b>

### 0.6.1 Flowmeters, Separate Chamber Top & Bottom (AFM supplied option )

Each furnace chamber area with a flowmeter is plumbed with a separate flowmeter for the chamber top and bottom. Allows for separate control of process gas flow above and below the belt.

### 0.6.2 Air Filter Regulator (AFR option , not supplied )

High volume compressed air filter, moisture trap and pressure regulator to assure supply compressed air is clean, dry and at the proper pressure before entering the furnace. If this option is not selected, customer must assure that an adequate supply of clean dry compressed gas not exceeding 5 bar (70 psig) is connected to the furnace.

### 0.6.3 Gas Reservoir (AR10 option , not supplied )

Pressure vessel for compressed air or nitrogen, 30-56 L (8-15 gal). Acts as a local reservoir to reduce process gas pressure fluctuations. Also can assure that in the event of process gas supply failure, an adequate supply of compressed gas is available to purge furnace of volatile or toxic gases.

Consists of an ASME tank, plumbing, pressure relief valve and drain.

### 0.6.4 Circuit Breaker (CB-3 supplied option )

A three phase circuit breaker can be installed in a lower panel or in an enclosure on the top of the furnace for convenient shutoff of the furnace when not in use. (Figure 0-18).

On three phase systems, the standard single phase circuit breaker switch is omitted.



Figure 0-18 3-Phase Circuit Breaker



## Section 0

### 0.6.5 European Certification (CE option , not supplied)

A strict implementation of CE requirements is followed according to the following documents:

Council Directive 2004.108/EC (EMC)

Council Directive 2006/42/EC (MSD)

Council Directive 2006/95/EC (LVD)

Compliance with all safety relevant provisions referring to:

- Controls
- Protection against mechanical hazards
- Required characteristics of guard and protection devices
- Protection against other hazards such as electrical, fire, noise and vibration



Figure 0-19 CE Mark

The following supplemental options must also be added to achieve the standard:

- Operation Manual for European Union (included)
- Circuit Breaker (must purchase CB-3 option separately)
- Line Filter (included)

### 0.6.6 Load Extension (CXE15 option , not supplied)

Increases standard 368 mm (14.5-inch) stainless steel Load station at the entrance of the furnace in 380 mm (15-inch) increments. Useful if a longer product load area is needed. (Similar to Figure 0-20)

Increases furnace length by a like amount.

### 0.6.7 Unload Extension (CXX15 , not supplied)

Increases standard 368 mm (14.5-inch) stainless steel Unload station length at the exit of the furnace in 380 mm (15-inch) increments. Used for product inspection or to provide a longer period for product removal.

Increases furnace length by a like amount.



Figure 0-20 LA-309 Unload station with CXX15

### 0.6.8 Dual Gas (DGO supplied option )

Dual gas systems can allow more expensive specialty gas to be introduced into the furnace chamber while another gas can be provided to all furnace auxiliaries.

#### A. DGO Equipment

Includes separate manifold for supply of a different gas to the furnace heating zones. Gas 1 can be CDA or nitrogen supplied to eductors. Gas 2 is usually nitrogen, forming gas or other specialty gas supplied to the furnace chambers, baffles, transition tunnels, and lamp plenums. The flowmeters may be in a different array to accommodate grouping of zone flowmeters for Gas 2 supply.

An alarm will sound if either Gas 2 supply is low in pressure. The Control Console will sound an audible alarm and the furnace software will provide visual indication for a low Gas 2 supply pressure condition.

#### B. DGO Operation

A furnace plumbed for dual gas is operated in much the same way as a single gas furnace.

1. Operators must assure that gas is flowing from both supply sources.
2. Dual gas systems have an alarm for Gas 2.
3. Typical systems will have CDA (air) supplied for Gas 1 and Nitrogen supplied for Gas 2. Alternatively nitrogen gas can be supplied for Gas 1 and forming gas supplied for Gas 2.



Figure 0-21 Control Enclosure showing Dual Process Gas Connections

### 0.6.9 Element Monitoring System (EM supplied option )

The Element Monitoring system is a lamp failure alert system that senses current in the lamps when firing and alerts users of an element or lamp failure if current is not detected when power is applied to the lamps.

### 0.6.10 H<sub>2</sub>/N<sub>2</sub> Mixing (HO/NHM option , not supplied )

Hydrogen/nitrogen mixing allows hydrogen and nitrogen to be introduced separately into the furnace gas mixing system where it is blended before being introduced into the furnace heating chamber.

#### A. HO/HNM Equipment

Hydrogen/nitrogen mixing requires the addition of a special gas mixing console and combustible gas sensors at key points on the furnace as well as additional flow and pressure sensors to assure the hydrogen introduced in an oxygen free furnace environment. Exhaust stack ignitors are also added to harmlessly flame any free hydrogen that maybe evacuated from the furnace.

#### B. HO/HNM Operation

Use of Hydrogen (H<sub>2</sub>) in the heating chamber requires special furnace owner safety considerations including:

1. Furnace installation ensuring proper ventilation and safe source gases,
2. Special warm up and cool down procedures must be followed.
3. Gas flow balance is critical to the safety of all personnel working near an infrared furnace operating with hydrogen process gas. Escaping hydrogen gas, or the admission of oxygenated gas into the process section is extremely hazardous.

These three elements ensure that no additional H<sub>2</sub> gas is allowed into the furnace and that the remaining H<sub>2</sub> is diluted and removed as quickly as possible.

## Section 0

Separate operating instructions will be provided for the HO/NHM option.

### 0.6.11 Supply Gas Mixing (GSM option , not supplied)

The GSM system option allows for rapid switching between two gas sources to the furnace heating zones. The GSM system provides pressure regulation of two gas sources at pressures within the range 100-3500 psig down to a furnace operating pressure of 70 psig.

Supply Gas 1 is typically nitrogen (N<sub>2</sub>) or air (CDA) and plumbed to all furnace areas including inlet baffle, stack eductor, transition tunnel and cooling section as well as through the Gas 1 flowmeter to the furnace heating zones.

Supply Gas 2 is typically nitrogen (N<sub>2</sub>) or forming gas (FG) and plumbed through the Gas 2 flowmeter to the furnace heating zones.

#### A. GSM Equipment

The GSM system includes two (2) high flow 0-3500 psig pressure regulators each with a 0-100 psi pressure gauge and flowmeter. Users can adjust for 100% forming gas to the furnace for critical reducing operations and later quickly switch to nitrogen to conserve higher cost specialty gas. User can also adjust flowmeters to increase amount of nitrogen in the forming gas mix (Figure 0-22).

The system can be ordered with alternate pressure ranges.

#### B. GSM Operation

To operate the furnace with Gas1 only (nitrogen):

1. Adjust Gas1 pressure.
2. Open Gas1 flowmeter and adjust Gas1 pressure to 70 psig.
3. Close Gas2 flowmeter.

To operate with Gas2 (forming gas) to furnace zones, Gas 1 to furnace auxiliaries:

1. Adjust Gas2 pressure.
2. Open Gas2 flowmeter and adjust Gas2 pressure to 70 psig.
3. Close Gas1 flowmeter.

To operate with both Gas1 and Gas2 to furnace zones, Gas 1 to furnace auxiliaries:

1. Adjust Gas1 and Gas2 pressure.
2. Open Gas1 flowmeter and adjust Gas1 pressure to 70 psig.
3. Open Gas2 flowmeter and adjust Gas2 pressure to 70 psig.
4. Adjust Gas1 and Gas2 flowmeters to achieve volume percent balance of gas entering the furnace chamber. Both should read the same pressure to assure even mixing.

**NOTE:** Note: Each GSM flowmeter is sized to accommodate full flow to all zones through the furnace. Consequently when the individual zone flowmeters on the Control Console are at low settings, the flow through the larger Gas1 and Gas2 flowmeters may appear to near zero if the sum of the flow is near the minimum operating range of the flowmeter (minimum is 10% of full flow).




Figure 0-22 Supply Gas Mixing System Control Panel

### 0.6.12 Handshake (HSK, supplied option ☑)

Normally Open and Normally Closed contacts supplied at entrance and exit of the furnace that are activated when PROCESS READY is reached. Facilitates notification to upstream and downstream equipment that the furnace is ready to process product.

### 0.6.13 Entrance Interface Rollers, IR-E, supplied option ☑ )

Small diameter (3-inch nominal) rollers installed at the entrance for easy loading of parts from other equipment.

(see Figure 0-23).




Figure 0-23 Interface Rollers

### 0.6.14 Exit Interface Rollers, IR-X), supplied option ☑ )

Small diameter (3-inch nominal) rollers installed at the exit for easy off-loading of parts to other equipment. (see Figure 0-23).

### 0.6.15 Line Filter (LFI option ☐, not supplied)

An AC power line interference filter reduces the potential electrical interference generated by SCRs and motor controls within the furnace. Compliant with IEC 60950. This option is included on furnaces with the European CE option.

### 0.6.16 Light Tower (LT, supplied option ☑)

Three color light tower that indicates when furnace is in Process Ready, Warmup or Alarm condition.



Figure 0-24 Light Tower

### 0.6.17 Moisture Analyzer (MA option , not supplied)

For processes that are sensitive to moisture, a moisture analyzer can provide status of monitored zones.

The moisture analyzer can be connected to any one sample port (with SSP option) or can be used with a 3-port sample system (OSS option).



Figure 0-25 MM510 Moisture Analyzer

#### A. MA Equipment

The brand of moisture analyzer can generally be specified by the owner. A high quality choice, the MM510 electrolytic moisture analyzer is designed for precise measurement of moisture in gas over a wide range (0.1 ppm to 1000 ppm with  $\pm 5\%$  accuracy). The analyzer is configured with an internal sample pump. The sample systems are manufactured using stainless steel throughout with 1/8-inch tube connections on the sample line. Sample flow is 0.05-0.5 L/min (50-500 cc/minute) controlled.

**MM510 Sensor.** The phosphorus pentoxide moisture sensor consists of a dual platinum winding formed around a quartz tube about 8 cm long. A constant voltage is applied across the windings and the current monitored. The moisture in the sample gas stream causes the resistance of the platinum coil to change. The change in resistance results in a change in measured current providing an absolute measure of the moisture contained in the process sample gas. Unlike aluminum oxide sensors, the phosphorus pentoxide sensor does not require annual factory calibration.

#### B. MA Operation

The model of moisture analyzer selected will be factory set for your application.

1. Startup of the furnace will start the moisture sampling if the analyzer is left enabled by the operator.
2. A switch on the back of the analyzer allows shutoff of the analyzer while the furnace is running, if desired.
3. Sample line flow is controlled by the valve knob on the back of the analyzer Adjust to 0.15 L/min.



### 0.6.18 Oxygen Analyzer (OA, supplied option )

This furnace is equipped with an oxygen analyzer and 3-port sampling system with source gas purge.

An oxygen analyzer can assure furnace settings result in a low oxygen environment in the furnace chamber during operation.

The EC913 process oxygen analyzer uses an electrochemical RACET™ cell for accurate measurement of oxygen (measuring range: 0.1 ppm-30% at ± 2%) and features microprocessor controlled functions, large auto-ranging LED display, and fast response. To avoid interference, indicate if hydrogen gas will be present.



Figure 0-26 EC913 Oxygen analyzer

The analyzer is fitted with an integral sample pump downstream of the sensor. The sample Out valve on the back of the analyzer is used for flow control and is adjustable from 0.05-0.5 L/min (50-500 cc/min) sample rate (default is 0.1 to 0.15 L/min).

On furnaces, the oxygen analyzer is usually mounted inside the furnace cabinet enclosure. The analyzer is integrated with the furnace control system. The oxygen concentration is displayed on the computer screen. Alerts and alarms are set in the process recipe on the computer.

Figure 0-28 shows the O2/MA Sample system control panel on furnaces equipped with a PC computer. The oxygen concentration for the selected zone is shown on the Process screen.



Figure 0-27 Oxygen analyzer next to OSS sample system

### 0.6.19 Sample System, Computer (OSS, supplied option )

OSS option provides user selection of any one of three (3) furnace ports or the source gas (nitrogen) to a sample gas line connected to the gas analyzer equipment (typically moisture and/or oxygen analyzer).

#### A. OSS Equipment

This system consists of electrical controls and piping of a 4-port manifold to a source gas and 3 sample ports. The sample ports are located on the bottom of each furnace chamber zone. The Source is piped from Gas1 (or the nitrogen source) through a pressure regulator adjusted to 35 mbar (0.5 psig) and a solenoid isolation valve and connected to the port 1 valve on the manifold.

#### B. OA Operation (Process Engineer level)

Start furnace and furnace software.

On the Process screen:

- select **O2 Port Select** button to open the O2 Sampling popup,
- click **O2 Sampling** radial button until **ON** is displayed to energize or de-energize system,
- Energizing O2 Sampling opens the selected port and starts analyzer and sampling pump.

System begins sampling the selected port. When starting system and changing ports, allow sufficient time for pump to completely purge sample (5-10 minutes or longer). During normal furnace operation, the sample system should remain on the most representative sample port during processing.

**Note:** When the sample line is dry, accurate readings can be obtained within 5-10 minutes. If the sample line contains moisture, it may take from 20 minutes to over 24 hours before accurate results can be obtained. See **Purging Sample Lines**.

#### C. OA Operation (Operator level)

Sampling system On/Off state and selected port are stored in each recipe. To enable system go to the Recipe screen and :

- Get recipe with **O2 Sampling and Port Select** predetermined in the recipe.
- O2 sampling will start when the furnace is started if the sampling system is enabled in the recipe.

#### D. Initial Startup

During initial startup, adjust analyzer OUT valve until Sample Flow flowmeter on front of analyzer reads 0.1-0.15 L/min (Figure 0-31). On subsequent startups, the flow rate does generally not need to be adjusted.

#### E. Purging Sample Lines

To speed drying time, moisture can be purged from the sample line by changing the Sample/Purge valve to PURGE and selecting each zone port for 5 minutes or longer to dry the lines. Return to SAMPLE mode for normal operation. To dry the line to the analyzer, disconnect the line from the analyzer and use a dry gas (nitrogen) to flush the line. Be careful to keep the pressure under 0.5 bar (7 psig) to avoid disconnecting the sample line from the furnace.

#### F. Shut Down Sampling System

On the Process Screen, click on O2 Sampling radio until **OFF** is displayed. Analyzer and pump shut down and sample system is isolated.

**Note A:** Analyzer valves can be left in open position while connected to the furnace because the sample port manifold will isolate the analyzer cell from gas flow when the system is off.




Figure 0-28 O2 ppmv and popup on Process screen




Figure 0-29 Sampling Recipe popup

## 0.6.20 Sample System, Manual (option )

The OSS option provides user selection of any one of 3 furnace ports or the source gas (nitrogen) to a sample gas line to the gas analyzer equipment (typically moisture and/or oxygen analyzer).

### A. OSS Equipment

This system consists of electrical controls and piping of a 4-port manifold to a source gas and 3 sample ports. The sample ports are located on the bottom of each furnace chamber zone. The Source is piped from Gas1 (or the nitrogen source) through a pressure regulator adjusted to 35 mbar (0.5 psig) and connected to port 1 on the manifold.

### B. Analyzer Initial Setup (with OSS)

Enable analyzer by turning Power Switch on back of analyzer (Figure 0-31) to ON position.

Open IN valve full CCW (on back of analyzer, (Figure 0-31).

**Note A:** In this configuration, analyzer will start and stop with the OA radial ON/OFF buttons in the furnace software.

### C. OA Operation (with OSS)

Start furnace and furnace software.

On the control panel:

select sample port using Port Select switch,

turn Analyzer ON switch to energize system and start analyzer.

During initial startup, adjust OUT valve until Sample Flow flowmeter on front of analyzer reads 0.1-0.15 L/min (Figure 0-31). On subsequent startups, the flow rate does generally not need to be adjusted.

**Note A:** When the sample line is dry, accurate readings can be obtained within minutes. If the sample line contains moisture, it may take from 20 minutes or longer. Moisture may be purged from the sample line by disconnecting the line from the analyzer and using a dry gas (nitrogen) to flush the line. Be careful to keep the pressure under 2.5 bar (35 psig) to avoid disconnecting the sample line from the furnace.

**Note B:** When nitrogen is connected to Gas 1, Port Select S will sample the source nitrogen. Ports 1, 2 and 3 sample the respective furnace zones.

### D. Shut Down Analyzer (with OSS)

If the analyzer is to be out of service for a period of time, further isolate the cell to prolong its life.

If system is not equipped with a check valve on the Sample OUT line, close OUT valve on back of analyzer (to isolate cell).

If analyzer is disconnected from the OSS, Close IN valve on back of analyzer (to isolate cell).

**Note A:** Analyzer valves can be left in open position while connected to the LA-309 as the sample port manifold will isolate the analyzer cell from gas flow when the system is off.

**Note B:** To prolong cell life, limit sampling of air.



Figure 0-30 Sample System control panel (shown with Supply Gas Mixing System)





Figure 0-31 EC913 Oxygen Analyzer Rear Controls

### 0.6.21 Over Temperature Alarm Operation (OT option , not supplied)

The Over Temperature Alarm system consists of independent redundant zone thermocouples, a scanner/annunciator and digital panel meter hardware integrated into the furnace software. The scanner/annunciator and digital panel meter are mounted on top of the furnace.

**NORMAL OPERATION.** The system scans each zone and passes a temperature signal to the digital panel meter. The operator can view the temperature on the panel meter and the respective zone being monitored will be indicated on the scanner

**ALARM.** If the temperature in any zone reaches the alarm set point, an alarm will sound in the scanner/annunciator and the furnace will go into Cool Down, the heating elements will be shut off by the controller. To silence the alarm, press ACK on the scanner/annunciator. The furnace cannot be restarted until the zone temperature drops below the alarm set point.



The OT system is in addition to the standard high/low temperature Alert/Alarm system included with the furnace software.

### 0.6.22 Cabinet Over Temperature (option , not supplied)

For high temperature furnaces (1000C), a secondary thermocouple can be attached near the center of the heating chamber between the chamber and the outside panel. The sensor is attached to an indicator to allow the user to monitor the cabinet temperature, which can reveal possible furnace control problems, cabinet fan failure, or blocked air inlets or exits.

### 0.6.23 Product Clearance (PH1, PH4 option , not supplied)

Furnace chamber with a product clearance of 50 mm (2 inches) is standard. As an option, alternate chamber sizes can be ordered.

**PH1** – Precision chamber height that will allow a maximum of 25 mm (1 inch) clearance above the belt for product. Allows for tighter temperature and atmospheric control.

**PH4** - Large chamber height that will allow a maximum of 100 mm (4 inches) clearance above the belt for product. Allows for large product processing at the expense of increased power and process gas requirements.

### 0.6.24 Pre-Purge, Nitrogen (PPG, supplied option )

The Nitrogen Pre-Purge system introduces a high volume of Gas2 process gas (nitrogen) into the furnace to purge the chambers of oxygen each time Furnace Warmup is initiated. The Pre-Purge system includes additional piping, valves and a regulator to provide a high volume of nitrogen for the purge. The Pre-Purge system initiation and duration are controlled by the furnace software. Furnace operators can determine the length of time the chamber must be purged before process gas flow returns to normal.

### 0.6.25 RAID (RAID, supplied option )

The RAID option provides for dual mirrored drive system on the furnace computer to increase reliability and decrease production downtime in the event of a computer drive failure. See the appendix for details if RAID has been supplied.



## 0.6.26 Product Alert (SENSLAS option )

The SENSLAS system alerts operators when product exits the furnace. For longer processes, operators can perform other tasks in the same work area and respond when product appears at the furnace Unload station (Figure 0-33).

### A. SENSLAS Equipment

This system consists of a laser sensor and audible chime with volume control. The SENSLAS system is conveniently controlled at vertical face of the furnace exit. The sensor is mounted on an adjustable bracket approximately 74-90 mm (3-3.5 inches) from the furnace exit (Figure 0-35).

### B. SENSLAS Operation

Easy to operate, the operator turns the system on using a lighted switch. Each time product passes under the sensor, the Clear button lights and a gentle audible chime continues to sound until the Clear button is pressed. Turning a four position selector switch changes the volume of the chime from quiet to loud. To disable the system, the ON/OFF switch is turned counter-clockwise (Figure 0-34).

1. Turn the SENSLAS Off/On clockwise.
2. Place hand under laser sensor and adjust the volume selector (1=low, 4=high) to desired sound level.
3. When parts pass under sensor, chime will sound and clear button lights until reset.
4. Press CLEAR button to reset chime.

When enabled, the system can be switched on and off at the furnace Control Console when either of the CONTROLS buttons is pressed.

### C. Sensor Calibration

The sensor can be calibrated using two objects: a sample of the product (foreground) and a thin flat sheet of metal or other material (background).

1. Turn on the SENSLAS system.
2. Set the belt at a slow speed (125-250 mm/min (5-10 ipm)).
3. Place the two objects in line just before the laser sensor with background object on the center of the belt first immediately followed by the foreground object.
4. As the background object passes under the laser beam, press calibrate button on the side of the sensor for less than 1 second Figure 0-35.
5. As the foreground object passes under the sensor press the button again for less than 1 second.

The SENSOR is now calibrated to sense objects between the height of the background and the foreground.



Figure 0-33 SENSLAS System



Figure 0-34 SENSLAS Control Panel




Figure 0-35 Calibrate Sensor



### 0.6.27 Sample Ports (SSP option )

This option includes control enclosure port connection to one or more of the sample ports located on the underside of each zone. Allows connection of an oxygen analyzer, moisture analyzer or other gas analyzer. Must be used with a sample pump (not included). Port connections are located under chamber. Figure 0-36 shows a typical port location on a chamber. Note: The chamber is fitted so that even if this option is not included at the time of manufacture, sample ports can be added later, if required.

Included with OA, MA and OSS options.




Figure 0-36 Sample Port Chamber Penetration

### 0.6.28 Low or High Belt Speed (option )

Standard belt speed is 25-500 mm/min (1-20 inches per minute). Alternate belt speeds can be offered increasing or decreasing the current min/max belt speed. Special conveyor belt speeds require changes to motor speed, power and gearing for this option.

This furnace is equipped with high belt speed option of 100-2000 mm/minute (4-80 ipm).

### 0.6.29 Ultrasonic Cleaner/Dryer (UCD option ) supplied)

This furnace is equipped with an ultrasonic belt cleaner dryer system integrated with the furnace software.

The ultrasonic belt cleaning system removes contamination that accumulates on the belt during normal furnace operation. This system includes a heated ultrasonic tank, belt dryer and timer system to enable automatic cleaning of the belt. A fan-driven air blow-off removes water droplets and can be provided with an optional heater to further drive moisture from the belt. The belt is drawn through an ultrasonic tank that is automatically filled and drained by computer controlled timer and control circuitry. The cleaning/drying of the belt takes place when the furnace is off-line.

This option requires connection to facility water source and water drain.




Figure 0-37 Ultrasonic Cleaner installation

### 0.6.30 Factory UPS (UPS, option supplied)

This option adds an uninterruptable power supply to keep the computer, monitor and PLC controller running for at least six (6) minutes in the event the power to the furnace is disconnected or during a power outage. The UPS provides time for the operator to properly power down the furnace computer using the Windows operating system.

When the furnace loses power either by:

- Throw open furnace circuit breaker

- Open EMO or interlock

- Loss of facility power

- Press Furnace Control Panel OFF

The belt and all auxiliaries will stop, but the computer, monitor and PLC will continue to run. Use the Windows™ “Shut down” procedure to shut down the computer. The PLC will shut down after 6 minutes or so.



Figure 0-38 Factory UPS

